



**iKoustic**  
Creating Quieter Spaces Together

# MuteGym™

## Light Maintenance Guide



EQUIPMENT	DETERGENT	DILUTE	COVERAGE	PADS & BRUSHES
<b>Initial Cleaning</b>	All Purpose Cleaner	25ml / 1L of Water	5 to 15 m <sup>2</sup> / L	Soft nylon brush
<b>Neutral Cleaning</b>	All Purpose Cleaner	40ml / 1L of Water	5 to 15 m <sup>2</sup> / L	Contact pad, purple pad, or soft nylon brush
<b>Heavy Soil Cleaner</b>	Floor Finish Stripper	10ml / 1L of Water	5 to 15 m <sup>2</sup> / L	Contact pad, purple pad, or soft nylon brush





# Light Maintenance Guide

## CLEANING INSTRUCTIONS

### IMPORTANT MAINTENANCE TIPS

1. Use high powered vacuum to pick up dust.
2. For large areas, use a rotary floor scrubber.
3. Dilute the detergents with water per the manufacturers instructions; use higher concentrations for stubborn stains or hard to clean areas.
4. Rinse, wet vacuum or mop up any detergent residue when cleaning the floor.
5. For gum, use generic gum remover; however, any solvent-based product should be rinsed well with water to avoid damaging your surface.
6. **DO NOT** use an Auto Scrubber with a squeegee attachment. It tends to not pick up all of the dirty water solution and leaves a film of diluted dirty water on the tiles.
7. **DO NOT** use petroleum or citrus-based detergents.

#### A – INITIAL CLEANING

1. Remove all surface soil, debris, sand and grit with a vacuum.
2. Scrub floor with a neutral detergent.
3. Pick up solution with a wet vacuum, rinse with clean water and allow to dry thoroughly.
4. This process may be done in one or two steps with a floor scrubber or SteamVac.

#### B – DAILY/REGULAR CLEANING

1. Sweep or vacuum floor to remove surface soil, debris, sand and grit.
2. Mop the floor with a damp mop.
3. This process may be done in one or two steps with a Floor Scrubber or SteamVac.
4. Allow floor to dry thoroughly.

#### C – INTERIM MAINTENANCE

1. Sweep or vacuum floor to remove surface soil, debris, sand and grit.
2. Mop the floor with a damp mop.
3. This process may be done in one or two steps with a Floor Scrubber or SteamVac.
4. Allow floor to dry thoroughly.

#### D – RESTORATIVE MAINTENANCE

1. Vacuum floor thoroughly.
2. Scrub using a rotary scrubber and Floor Finish Stripper.
3. Pick up solution with a wet/dry vacuum or SteamVac.
4. Allow floor to dry thoroughly.

### EQUIPMENT SPECIFICATIONS

EQUIPMENT	SPECIFICATIONS
<b>SteamVac Machine</b>	Similar to any <b>SteamVac</b> model with scrubber and vacuum.
<b>Rotary Floor Scrubber</b>	<b>Rotary Floor Scrubber</b> with a 33cm cleaning width is your best option to clean <b>DuraSound</b> . It works well in large areas and is especially manoeuvrable around equipment.
<b>Power Scrubber</b>	43cm rotary floor buffer with mounted detergent tank and feed line to the brush. A circular brush attachment should be used.
<b>Wet/Dry Shop Vacuum</b>	<b>Power Unit:</b> Minimum 1.7 hp commercial unit, 7.0 amp, 120 volt AC, 50/60 Hz two stage bypass motor. Tank Capacity: 45-60L , lined stainless steel or polypropylene. Accessories: Extension wand with a 15-30cm pickup nozzle, crevice tool & heavy duty extension cord.
<b>Detergent</b>	Commercial/Industrial non-petroleum based neutral detergent: <ul style="list-style-type: none"> <li>• <b>Mr Muscle Floor Cleaner</b></li> <li>• <b>Jantex Floor Finish Stripper</b></li> </ul>



Broom



Wet Mop



Vacuum



Buffer



Steam Vac



Floor Scrubber

